



VIDEO TUTORIAL

### Important!


This replacement procedure can be used for:

VW CADDY II Box (9K9A) 1.9 D, VW GOLF III (1H1) 1.9 D, VW GOLF III Variant (1H5) 1.9 D, VW PASSAT (3A2, 35I) 1.9 D, VW PASSAT Variant (3A5, 35I) 1.9 D, VW VENTO (1H2) 1.9 D

---

The steps may slightly vary depending on the car design.

## REPLACEMENT: STRUT MOUNT – VW GOLF 3. TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Torque wrench
- Combination spanner #17
- Drive socket # 10
- Drive socket # 17
- Wheel impact socket #17
- Ratchet wrench
- Tap wrench
- Shock absorber socket #DD5,2
- Hydraulic strut spring compressor
- Hydraulic transmission jack
- Wheel chock

## Replacement: strut mount – VW Golf 3. Professionals recommend:

- The replacement procedure is identical for the mounts of the left and right shock struts of the rear suspension.
- All mounts of the rear shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.

## REPLACEMENT: STRUT MOUNT – VW GOLF 3. TAKE THE FOLLOWING STEPS:

1



Open the boot lid.

2



Move the folding shelf and detach it from the retainers. By doing this, you will get access to the side trim plastic panels.

3



Unscrew the fasteners of the side plastic trim panel. Use a drive socket #10. Use a ratchet wrench.




4



Remove the side plastic cover.

5



Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.

**6**


Loosen the upper fastener of the shock strut mount. Use a combination spanner #17. Use a shock absorber socket #DD5,2. Use a ratchet wrench.

**7**


Secure the wheels with chocks.

8



Loosen the wheel mounting bolts. Use wheel impact socket #17.

9



Raise the rear of the car and secure on supports.



10



Unscrew the wheel bolts.

### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. VW Golf 3

11



Remove the wheel.

12



Clean the shock strut fasteners. Use a wire brush. Use WD-40 spray.

13



Support the rear suspension beam. Use a hydraulic transmission jack.

14



Unscrew the lower fastener of the shock absorber strut. Use a combination spanner #17. Use a drive socket #17. Use a tap wrench.

15



Unscrew the top fastening of the shock strut mount.

### AUTODOC recommends:

- To avoid injuries, hold the shock strut when undoing the fastening bolts.



16



Remove the mounting from under the rear axle beam.

### Replacement: strut mount – VW Golf 3. Tip:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

17



Remove the fastening bolt.



18



Remove the suspension strut.

19

Set the shock absorber strut on the spring compressor tool.

### AUTODOC recommends:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

20



Remove the top strut mount.

### Replacement: strut mount – VW Golf 3. AUTODOC recommends:

- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

21



Treat the shock strut rod. Use a wire brush. Use WD-40 spray. Use copper grease.

22



Install a new strut mount.

23

Remove the assembled shock strut.

24



Treat the mounting seats of the shock strut. Use a wire brush. Use WD-40 spray.

25



Install the shock strut into the wheel arch.

26



Support the rear suspension beam. Use a hydraulic transmission jack.

27

Install the fastening bolt.



28



Screw the top fastening of the shock strut mount. Do not tighten it.

### AUTODOC recommends:

- VW Golf 3 – To avoid injury, hold the suspension strut while screwing in the fastening bolts.

29



Screw in the lower fastener of the shock strut. Use a combination spanner #17. Use a drive socket #17. Use a tap wrench.

30



Tighten the lower fastening of the shock absorber. Use a combination spanner #17. Use a drive socket #17. Use a torque wrench. Tighten it to 85 nm torque.

31




Remove the mounting from under the rear axle beam.

## AUTODOC recommends:

- Replacement: strut mount – VW Golf 3. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

32



Treat the shock strut fasteners. Use copper grease.

33



Clean the wheel rim mounting seat. Use a wire brush.



34



Treat the surface where the wheel rim contacts the brake drum. Use copper grease.

35



Install the wheel.

## AUTODOC recommends:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

36



Screw in the wheel bolts. Use wheel impact socket #17.

37



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.

38



Remove the jacks and chocks.

39



Tighten the upper fastener of the shock absorber strut mount. Use a combination spanner #17. Use a shock absorber socket #DD5,2. Use a torque wrench. Tighten it to 60 Nm torque.

40



Treat the fasteners of the shock strut mount. Use copper grease.

41



Install the side plastic panel.



42



Screw the fasteners of the side plastic trim panel. Use a drive socket #10. Use a ratchet wrench.

43



Install the folding shelf to its mounting seat.

44



Close the lid of the luggage compartment.

**DID YOU FIND THESE INSTRUCTIONS  
HELPFUL?**

**YES**

**NO**



**BECOME A MEMBER OF AUTODOC CLUB!**



## AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



The image shows two smartphones displaying the Autodoc mobile app. The foreground phone shows a 'Bildelkatalog' (Image Catalog) for Mercedes-Benz 100 Platform-C, featuring a '23% RABATT PÅ RESERVEDELER' (23% discount on spare parts) banner. Below the banner, it lists categories: 'ALLE KATEGORIER:' (All categories), 'Vindusvask' (Windshield wipers), 'Oljer og Væsker' (Oils and fluids), 'Bremseanlegg' (Brake system), and 'Filter' (Filters). The background phone shows a collection of car parts on shelves. To the right of the phones, the 'AUTODOC APP' logo is displayed above three download buttons: 'Download', 'Google play', and 'App Store'.

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



## BUY SPARE PARTS FOR VW



## STRUT MOUNT: A WIDE SELECTION



### CHOOSE CAR PARTS FOR VW GOLF 3



### STRUT MOUNT FOR VW: BUY NOW



## STRUT MOUNT FOR VW GOLF 3: THE BEST DEALS & OFFERS



### Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.